

Drone Landing Surface Analysis & Safe Landing Zone Identification

Progress Report

March 27, 2025

1 Introduction

This section details the process of segmenting Martian surface point cloud into smooth (flat) and rough (curved) regions using statistical methods. The approach is unsupervised and relies on local geometry analysis through k-nearest neighbors (kNN), Principal Component Analysis (PCA) for curvature estimation, thresholding, and clustering. This segmentation method is particularly useful for applications such as safe landing zone detection and autonomous navigation.

2 Local Geometry Estimation

2.1 Objective

We aimed to determine the local shape and “roughness” of the surface at each point in the point cloud by examining its nearby points.

2.2 Methodology

Every point on the surface possesses a local neighborhood that carries essential information about the surface geometry. We analyzed these neighborhoods using k-nearest neighbors (kNN) to capture the local geometry.

- **k-Nearest Neighbors (kNN):** For each point p , we identified its k nearest neighbors. This neighborhood was assumed to accurately represent the local geometry.
- **Principal Component Analysis (PCA):** We applied PCA to the set of neighboring points to compute the covariance matrix. The eigenvalues and eigenvectors obtained from the covariance matrix reveal the principal directions of variance.

3 Curvature Estimation via PCA

3.1 Objective

Our goal was to quantify the “flatness” of a local region by computing a curvature metric.

3.2 Procedure

For each point p with its k -nearest neighbors $\{p_1, p_2, \dots, p_k\}$:

(a) **Centroid Calculation:**

$$\bar{p} = \frac{1}{k} \sum_{i=1}^k p_i$$

(b) **Covariance Matrix Construction:**

$$\Sigma = \frac{1}{k} \sum_{i=1}^k (p_i - \bar{p})(p_i - \bar{p})^T$$

(c) **Eigen-Decomposition:** The eigenvalues $\lambda_1 \leq \lambda_2 \leq \lambda_3$ and corresponding eigenvectors of Σ were computed.

(d) **Curvature Metric:** We defined the curvature κ as:

$$\kappa = \frac{\lambda_{\min}}{\lambda_1 + \lambda_2 + \lambda_3}$$

where λ_{\min} is the smallest eigenvalue. A low value of κ indicated that the local surface was smooth or flat.

3.3 Interpretation

- **Low κ :** Indicates that the variance in the normal direction is small compared to the overall variance, suggesting a flat region.
- **High κ :** Implies significant variance in the normal direction, meaning the region is rough or curved.

4 Thresholding for Segmentation

4.1 Objective

We aimed to differentiate between smooth and rough regions by applying a threshold on the curvature metric.

4.2 Methodology

After computing the curvature for every point, a threshold τ was set. Points with $\kappa \leq \tau$ were classified as lying on smooth surfaces, while points with $\kappa > \tau$ were deemed rough.

4.3 Rationale

- **Statistical Filtering:** The thresholding process filtered out points with high curvature, thus effectively distinguishing between smooth and rough areas.
- **Adjustability:** The threshold τ was adjustable, enabling us to fine-tune the segmentation based on the data's characteristics.

5 Clustering and Region Growing

5.1 Objective

We sought to group individual smooth points into contiguous regions, thereby reducing the impact of isolated misclassifications.

5.2 Methodology

- After thresholding, spatial clustering (e.g., region growing or connected component analysis) was performed to group neighboring points that were classified as smooth.
- This clustering allowed us to identify extended regions that were consistently flat.

6 Overall Rationale and Advantages

6.1 Unsupervised Approach

- **No Labeled Data Required:** The method was entirely unsupervised, relying solely on the statistical properties of the point cloud.
- **Flexibility:** It can be applied to various datasets and environments without the need for pre-labeled training data.

6.2 Statistical Robustness

- **Data-Driven Analysis:** The approach leverages the inherent spatial distribution of points, making it robust to noise and variations.
- **Multi-Scale Analysis:** Although a fixed neighborhood size was used, the method can be extended to analyze multiple scales for enhanced segmentation.

6.3 Practical Implications

- **Safe Landing and Navigation:** The segmentation enabled the identification of flat, safe regions suitable for applications like landing site detection and autonomous navigation.
- **Wide Applicability:** The method is adaptable to different types of point cloud data, from aerial LiDAR scans to indoor depth sensor outputs.

7 Conclusion

We successfully performed statistical segmentation of a point cloud by:

- (i) Analyzing local geometry using k-nearest neighbors and PCA.
- (ii) Quantifying local curvature with a normalized curvature metric.
- (iii) Applying a threshold to classify regions as smooth or rough.

(iv) Grouping smooth points via clustering to delineate contiguous flat areas.

This unsupervised, data-driven approach proved robust and adaptable, providing a reliable method for identifying safe, flat regions in complex point cloud data.